

LAPEL MIC INSTRUCTIONS

1. Make sure beltack is set to Mic Line
2. Attach lapel Mic clip to top of shirt directly under your mouth
3. Using the Mic Key (in box-please make sure it is returned), set Mic gain on beltack at lowest setting (counterclockwise)
4. Set PA system to wireless receiver mic volume at a quarter volume
5. Ensure beltack and PA system are on the same wireless channel
6. Adjust mic gain up slowly to desired sensitivity until you reach desired volume. Mic gain may vary with each unit.

Note: Increasing mic gain will increase the chance of feedback as it is increasing mic sensitivity.

If you are getting feedback but need more volume lower the mic gain and increase volume on PA system.

To reduce the chance of feedback the PA system should be placed in front of the presenter with mic.

Note: The LM-60 lapel mic functions optimally indoors and with minimal head movement as the mic is a uni-directional lapel microphone.